

CUT/PINCH HAZARD: SHARP BLADES AND/OR COMPONENTS. ANY IMPROPER USE OF BLADES OR TOOL COMPONENTS INCLUDING CHISELING, ICE PICKING, AWLING, PRYING, APPLYING FORCE ONTO BACK OF BLADE/COMPONENTS, OR CONTACT WITH BLADES/COMPONENTS MAY RESULT IN INJURY OR CAUSE DAMAGE. KEEP BLADES AWAY FROM FINGERS AND BODY. DO NOT STRIKE THE KNIFE WITH ANOTHER OBJECT. DO NOT USE IF THE BLADE OR TOOL COMPONENTS ARE DAMAGED OR LOOSE. ONLY DEPLOY AND USE ONE TOOL COMPONENT AT A TIME. HANDLE WITH CARE. STORE TOOL IN ITS SHEATH OR IN A SAFE PLACE WHEN NOT IN USE. KEEP OUT OF REACH OF CHILDREN.

USA ▲ CAUTION



BUCK BOURBON
1049 McDONALD ROAD
LAWRENCEBURG, KY 40342-9597
BUCKBOURBON.COM


WARNING! BEFORE CHANGING BLADES READ AND UNDERSTAND THE ENCLOSED WARNINGS.



WARNING! BEFORE CHANGING BLADES READ AND UNDERSTAND THE ENCLOSED WARNINGS.



WARNING! BEFORE CHANGING BLADES READ AND UNDERSTAND THE ENCLOSED WARNINGS.




To remove a blade (For fixed handle model, skip to step 2.)

1. Carefully open the knife and ensure that the liner lock is firmly engaged to prevent the blade from folding while you are changing blades.
2. Carefully support the knife handle with one hand, while pressing the spring-loaded blade retaining latch located in the curved cut-out on the blade mount's spine.
3. Carefully grasp the flat sides of the front portion of the replacement blade and gently but firmly pull it forward out of the blade mount.



WARNING! BEFORE CHANGING BLADES READ AND UNDERSTAND THE ENCLOSED WARNINGS.



To insert a blade

1. Carefully support the knife handle with one hand, while pressing the spring-loaded blade retaining latch located in the curved cut-out on the blade mount's spine.
2. Carefully grasp the flat sides of the front portion of the replacement blade and gently but firmly insert the rear portion into the blade mount until the blade latches into place with an audible and tactile click. Release blade retaining latch.
3. Carefully grasp the flat sides of the front portion of the replacement blade and gently but firmly pull on the blade you have just inserted to make sure it is fully latched into place.
4. For folding handle model, press the liner lock and carefully close the knife.